


Dresser

900000122



leeftijd
age **3+**



Let op: bestudeer deze bouwhandleiding zorgvuldig vóór montage. Montage alleen door volwassenen. SVP deze informatie bewaren ter referentie.
NOTE: Please read instructions before starting to assemble. Adult assembly required. Please retain this information for reference.

A X1	B X1	
C X1	D X1	E X1
F X1	G X1	H X1
I X1	J X2	K X1

L X1	M X2	N X1
O X2	P X2	Q 301327 M4x20 X2
R 360378 M4x20 X7	S 367134 M6x31 X3	T 301931 M6x22 X4
U 304267 M4x37 X8	V 367135 φ15x9.5 X3	W X1
X X1		

667195.200529

